



bObi Classic

OWNER'S MANUAL

bObi Classic

OWNER'S MANUAL

Model SW603002
Manual Version 2020.1



Congratulations!

Congratulations on your new intelligent floor cleaner! bObi is now at your service. To see bObi at her best, please read the Quick Start Guide and this manual thoroughly.

Welcome to the bObsweep family and Happy Sweeping!

If you have any questions or concerns, feel free to contact our helpful support team at support@bobsweep.com or [1-888-549-8847](tel:1-888-549-8847).
Our business hours are Monday – Friday, 9 a.m. – 5 p.m. Pacific Time.

bObi

Important Safety Instructions

Flip bObi's power switch OFF and unplug her from the outlet when she is not in use and before conducting maintenance.

bObi is not intended for use by persons (including children) with reduced physical or mental capabilities, or lack of experience and knowledge, unless under the close supervision of a person responsible for their safety.

Leaks from the battery cells can occur under extreme usage or temperature conditions. If the liquid gets on the skin, wash quickly with water. If the liquid gets into the eyes, flush them immediately with clean water for a minimum of 10 minutes, and seek medical attention.

bObi is composed of electronic components that in rare and unintended cases can cause hazards of heating, fire, and other malfunctions. Furthermore, because bObi is capable of autonomous movement, her use poses the risk of collision with property, pets, and persons. Unintended removal of articles — such as small valuables, jewelry, or hair of persons or pets lying on the floor — may also occur.

If bObi, her remote control, or her charging station has been damaged in any way, do not operate them. Contact our helpful support team at support@bobsweep.com or or [1-888-549-8847](tel:1-888-549-8847).

✗ Do not handle bObi, her remote, or her charging station with wet hands; use only on dry surfaces.

✗ Do not pull or carry the charging station by the cord, use the cord as a handle, close a door on the cord, or pull the cord around sharp edges or corners. Keep the cord away from heated surfaces. To unplug the cord, grasp the plug, not the cord.

✗ Do not attempt to open the charging station. Repairs on the station should only be carried out by our qualified technicians.

✗ With the exception of the mopping cloth, do not immerse any part of bObi into water or other liquids.

✗ Do not mutilate or incinerate the battery, as it will explode at high temperatures.

✗ Do not use bObi outdoors.

✗ Do not expose bObi, her charging station, or remote to temperatures higher than 113° F (45° C), moisture, or humidity.

✗ Do not dispose of your battery in fire. Old batteries should be recycled safely through your local recycler.

✗ Do not let bObi pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

Declaration of Conformity

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warranty

Every bObi Classic purchased from an authorized seller includes a 1-year limited warranty, 5-year subsidized repair plan, and lifetime of customer support. The warranty covers the battery, labor, and non-consumable parts; it does not cover postal charges and consumable parts such as brushes, filters, and mopping cloths.

To activate bObi's warranty, register her online at www.bobsweep.com/warranties. To purchase additional coverage plans, go to www.bobsweep.com/coverageplans.

Table of Contents

4 Getting Started

- 5. Box Contents
- 7. bObi's Anatomy
- 9. Get to Know bObi
- 14. Get bObi Started

22 Charging

- 23. Charging bObi
- 25. Charging Station
- 27. Syncing the Charging Station

30 FullCommand™ Remote

- 31. Remote Buttons
- 33. Syncing the Remote
- 35. Navigating bObi

38 Cleaning Schedule

- 39. Setting the Current Time and Day
- 41. Setting the Cleaning Schedule
- 43. Auto-Resume Mode

46 Maintenance

- 47. Dustbin
- 49. Filter
- 51. Main Brush
- 53. Side Brush
- 55. Sensors
- 57. Front Wheel

60 Parts and Accessories

- 61. Mop
- 63. Edge Sensors
- 65. Battery

68 Troubleshooting

- 69. Edge Sensors
- 71. Brushes
- 73. Power System
- 75. Wheels
- 77. Dustbin

80 Home Checkup Test

- 81. Putting bObi in Checkup Mode
- 83. Home Checkup Test Steps

86 FAQs

94 End User License Agreement

Getting Started

Let's start at the very beginning.


We'll walk you through the basics and help you get bObi started for the very first time.

- 5 Box Contents
- 7 bObi's Anatomy
- 9 Get to Know bObi
- 14 Get bObi Started




Bob comes with the following items. You can purchase replacement parts and accessories at www.bobsweep.com/shop.

- | | |
|--|--|
| 1 FullCommand™ Remote | 10 Side Brush Screws (2) |
| 2 Charging Adapter | 11 Blindfold Stickers (4) |
| 3 Charging Station | 12 Cleaning Tool |
| 4 Microfiber Mopping Cloths (2) | 13 Main Brush |
| 5 Mop Attachment | 14 Side Brush |
| 6 Battery | 15 Main Brush Holders (2) |
| 7 Filter | 16 Owner's Manual, Quick Start Guide, and Warranty Card |
| 8 Phillips Head Screwdriver | 17 bObi Classic™ |
| 9 Syncing Tool | |




Top View



Cover Buttons

- 1 GO! - Sends bObi to clean.
- 2 JUICE - Sends bObi to her charging station.
- 3 WAFFLE - Sends bObi to clean localized mess.

Bottom View





Who is bObi?

bObi is an autonomous robotic vacuum cleaner, at your service! She can vacuum, sweep, and mop all the same time — and at the end of her cleaning session, she automatically returns to her charging station for a power nap. Set bObi to clean on a schedule and she'll clean on her own even when you're not around.


How does bObi find her way around?

bObi doesn't store any data about your home; instead, she uses a network of reactionary sensors to detect obstacles. To maximize her coverage, she may spiral outward, zigzag across a small area, or follow along walls. If she seems to be ignoring some spaces or spending too much time on others, don't worry! bObi will efficiently clean your home over the course of a full cycle — just check her dustbin for the evidence!




Should I pick up bObi?

You may pick up bObi while she's cleaning, but it's best to let her work in her own way. Moving her around, manipulating her movements, or picking her up may confuse her and disrupt her cycle.




FullCommand™ Remote

If you wish to control bObi's movements manually, you may use the navigational buttons on her remote.




bIOck™

You can keep bObi away from obstacles that she finds difficult to navigate, such as areas with cords or high ledges, by using bIOck*.



Charging Station

bObi automatically returns to her charging station when low on battery. If bObi is having trouble finding her station, try re-syncing it and relocating it to a more easily accessible location with more space around it.



Mop Attachment

bObi may have a tough time climbing over elevated surfaces while mopping. Remove bObi's mop when she is not cleaning smooth surfaces. Do not let her climb onto carpet or rugs when mopping.

* Available to purchase separately.

Navigating Difficult Obstacles

Unique Furniture

bObi is designed to maneuver around furniture of most shapes and sizes, but she may find it difficult to clean under chairs with narrow legs or around furniture that is too low for her sensors to detect. Specialty furniture, such as desk chairs with wheels or stools with circular bases, may also confuse her — but don't worry, bObi usually finds her way around with time.

Dark-Colored Carpet

If bObi repeatedly backs up or displays an error message while cleaning dark carpet, then you'll need to deactivate the edge sensors. To do so, simply use bObi's blindfold stickers to cover her edge sensors. Just remember that while bObi's edge sensors are deactivated, she will not be able to detect edges or stairs!

Shag Carpet

bObi's main and side brushes are not designed to clean shag carpet or rugs with long fibers. If you'd like bObi to clean shag carpet or long-fibered rugs, you may remove her main and side brushes and allow her to vacuum without it.

Inclines

Sometimes bObi will attempt to drive up angled surfaces, get stuck for a few minutes, and then decide to clean somewhere else. As long as bObi does not stop and display an error message on her remote's screen, let her continue cleaning and find her own way around. Take note of the areas bObi finds the most challenging and, if possible, adjust your furniture accordingly.


Easy Fix

Use bIOck*, bObi's add-on accessory, to keep bObi away from areas she finds particularly challenging. bIOck emits a digital barrier that bObi won't cross.

* Available to purchase separately.

Step 1: Install bObi's Battery



Parts You'll Need:




Battery




Phillips Head
Screwdriver



1. Remove the 2 screws on the battery cover using a Phillips head screwdriver.



2. Plug the battery into its socket, then slide the battery into the compartment.




3. Replace the screws on the battery cover.


Step 2: Charge bObi

Allow bObi to fully charge before using her for the first time.

Parts You'll Need:



Charging Adapter



Charging Station



When bObi Is Charging:

The charging indicator's center light will flash to indicate that she is charging.




When bObi Is Fully Charged:

The light remains still.



1. Plug the charging adapter into the side of the charging station. The station's power light will turn on.




2. Place bObi on her charging station with the metal nodes on her front resting against the plates on her station.


Step 3: Prepare bObi's Remote

Setup bObi's remote so that she can respond to its commands.

Parts You'll Need:



FullCommand™
Remote





AAA Batteries x2
(not included)

Quick Tip:





Make sure to remove the clear plastic covering on bObi's power switch.




Insert 2 x AAA batteries to turn on bObi's remote.

bObi is now ready to clean!



1. Flip bObi power switch ON.

2. Press the GO! button on bObi's cover or FullCommand™ remote, and she will clean on her default Deep Clean mode.



Quick Tip:

Make sure to remove the clear plastic covering on the power switch.


Charging

bObi automatically returns to her charging station when low on battery. To maximize bObi's chance of finding her station, it's best to place it in an easily accessible location with plenty of space around it. If bObi continues to have trouble finding her station, you may need to sync it.

- 23 Charging bObi
- 25 Charging Station
- 27 Syncing the Charging Station




Charging bObi




Charging bObi Using the Charging Station

Place bObi on her charging station with the metal nodes on her front resting against the plates on her station. Make sure the station is plugged in and the station's power light is on.



Charging bObi Using the Adapter

Plug the charging adapter directly into the inlet on bObi's side.



Sending bObi to Her Charging Station

Press the JUICE button on her FullCommand™ remote or cover.



When bObi Is Charging:


Charging indicator's center light will flash to indicate that she is charging.

When bObi Is Fully Charged:

The light remains still.

Charging Station

Position the charging station against a wall on a hard, flat surface. Make sure there is at least 10 feet (3 m) of open space to the front and 2 feet (0.6 m) of open space to the sides of the station.



Conserving bObi's Battery

To conserve bObi's battery, turn her power switch OFF and remove her from her charging station when she is not in use. bObi should not sit on her station for more than 5 days.

Standby Mode

After a minute of idling with her power switch ON, bObi will enter standby mode to conserve her battery. In standby mode, bObi will beep once every 2 minutes. To mute the beeps bObi makes in standby mode, turn her power switch OFF or place bObi on her charging station.




When bObi is charging, the charging indicator's center light will flash to indicate that she is charging.

When bObi is fully charged, the light remains still.


Syncing the Charging Station

bObi is smart and will automatically search for her charging station when her battery power reaches 15%. You will need to sync the station if bObi is having trouble finding it.



Parts You'll Need:




Charging Adapter



Charging Station



1. Plug the charging adapter into the side of the charging station. The station's power light will turn on.



2. Using the syncing tool, press the SYNC button on the back of the charging station while at the same time flipping bObi's power switch ON.

Quick Tip:

! Make sure bObi is not on the charging station during the sync.



bObi will chirp twice to let you know the sync was successful. If bObi does not chirp, repeat the process.

FullCommand™ Remote



You can set bObi's cleaning schedule, select her cleaning modes, and control her movements all from her FullCommand™ remote.

- 31 Remote Buttons
- 33 Syncing the Remote
- 35 Navigating bObi



Remote Buttons


- 1** GO!
Sends bObi to clean.
- 2** Juice
Sends bObi to her charging station.
- 3** Waffle
Sends bObi to clean a localized mess.
- 4** Hi/Bye
Puts bObi in and out of standby mode.
- 5** OK
Confirms time selection or synchronizes the remote.
- 6** Speed
Slows bObi down for an intensive clean or speeds her up to her default speed.
- 7** CUR Time
Sets the current time and day.
- 8** SCH Time
Sets bObi's cleaning schedule.
- 9** All/None
Shortcut to select/deselect all weekdays.
- 10** UV Light
Activates or deactivates the UV light.
- 11** Stop
Pauses or resumes bObi's movements.
- 12** Navigational Buttons
Guide bObi forward, backward, right, or left.




bObi's FullCommand™ remote requires 2 AAA batteries (not included). Remove the batteries if you are not using the remote on a regular basis. Keep the remote at room temperature.

Syncing the Remote

bObi must be synced to her FullCommand™ remote before she is able to obey its commands.




Parts You'll Need:




FullCommand™ Remote



AAA Batteries x2 (not included)



1. Hold down the OK button on bObi's remote.




2. While still holding down the OK button, flip bObi's power switch ON.



bObi will chirp twice to let you know the sync was successful. If bObi does not chirp, repeat the process.


Navigating bObi

Hold down a navigational button on the remote to keep bObi moving in the desired direction.
Release the button when you are done manually driving bObi.



Quick Tip:

- ⓪ bObi's edge sensors are located along her front, not along her back. Do not reverse bObi towards edges, as she will fall.



Cleaning Schedule

bObi can be programmed to clean at the same time on multiple days of the week through her FullCommand™ remote. The remote works on a 24-hour clock, so adjust accordingly.


- 39 Setting the Current Time and Day
- 41 Setting the Cleaning Schedule
- 43 Auto-Resume Mode



Setting the Current Time and Day

bObi can be programmed to clean at the same time on multiple days of the week through her FullCommand™ remote. To set bObi's cleaning schedule, you must first set the current time and day on her remote. Make sure bObi is turned ON and synced to her remote before proceeding.

Parts You'll Need:





FullCommand™ Remote




AAA Batteries x2 (not included)

The remote works on a 24-hour clock, so adjust accordingly.



1. Press the CUR TIME button on the remote. The first hour digit will start flashing.



2. Use the LEFT and RIGHT buttons to move between minutes, hours, and days of the week. Use the FWD and BACK buttons to adjust your selection.




3. Press the CUR TIME button again to save your settings. bObi will chirp to confirm your save.


Setting the Cleaning Schedule

bObi can be programmed to clean at the same time on multiple days of the week through her FullCommand™ remote. After setting the current time and day on bObi's remote, you may set her cleaning schedule. Make sure bObi is turned ON and synced to her remote before proceeding.

Parts You'll Need:



FullCommand™ Remote



AAA Batteries x2 (not included)



The remote works on a 24-hour clock, so adjust accordingly.

Important to Note:


 The remote keeps its cleaning schedule for 4 hours after the batteries are removed.

Quick Tip:


 To clear bObi's schedule, press the SCH TIME button and go through each day of the week, pressing OK to deselect. The days of the week that are selected will be lit.




1. Press the SCH TIME button on the remote. The first hour digit will start flashing.



2. Use the LEFT and RIGHT buttons to move between minutes, hours, and days of the week. Use the FWD and BACK buttons to adjust your selection.



3. Press the OK button to select or deselect days of the week. The days of the week that are selected will be lit.




4. Press the SCH TIME button again to save your settings. bObi will chirp to confirm your save.


Auto-Resume Mode

On auto-resume mode, bObi leaves her charging station after every recharge to perform “back-to-back” cleaning cycles. To enable auto-resume, make sure bObi is turned ON and synced to her FullCommand™ remote.

Parts You'll Need:





FullCommand™ Remote




AAA Batteries x2 (not included)


Enabling Auto-Resume



1. Press the SCH TIME button on the remote.




2. Press the STOP button and “FFGO” (finish fueling and go) will appear on the remote’s screen.




3. Press the SCH TIME button again to save your settings.


Disabling Auto-Resume



1. Press the SCH TIME button on the remote.



2. Press the STOP button and “FFGO” will reset to the last saved time.



3. Press the SCH TIME button again to save your settings.

Maintenance

To maximize bObi's efficiency, it is best to clean her dustbin, filters, brushes, and sensors about once a week.


- 47 Dustbin
- 49 Filter
- 51 Main Brushes
- 53 Side Brush
- 55 Sensors
- 57 Front Wheel



Dustbin

To maximize bObi's efficiency, it is best to empty her dustbin about once a week, or about once every 6 cleaning cycles.

Parts You'll Need:





Cleaning Tool


Emptying bObi's Dustbin

Quick Tips:


-  Never fill the dustbin with water or any other liquid with the vacuum motor attached.
-  Do not force the dustbin gate past its natural opening point.
-  Do not remove the dustbin while bObi is upside down.




1. Hold down the eject button on the back of the dustbin, and slide the dustbin out.



3. Wipe the dustbin with a dry cloth or brush it with bObi's cleaning tool. Carefully close the gate and slide the dustbin back into bObi.



2. Pull up the two color clips on either side of the dustbin with both hands. This will release the gate. Carefully open the gate and dump out the contents of the dustbin.




4. To wash the dustbin, first remove the vacuum motor and filter. Press the button on top of the dustbin to remove the vacuum motor.

Filter


To maximize bObi's efficiency, it is best to clean her filter about once a week and replace it about once every 6 months. The filter is located inside the dustbin. These filter captures fine particles and prevents them from escaping the dustbin.

Parts You'll Need:




Cleaning Tool

Cleaning bObi's Filter




Quick Tip:


Do not wash bObi's filter with water or any other liquid.




1. Push the button on bObi's back and slide the dustbin out.



3. Remove the filter and brush it with bObi's cleaning tool.



2. Open the gate and flip the dustbin upside-down to open the filter compartment.



4. Replace the filter and slide the dustbin back into bObi.

Main Brush

bObi uses a dual brush cleaning system. It is recommended that you open and clean bObi's main brushes once a week.

Parts You'll Need:





Cleaning Tool


Cleaning bObi's Main Brushes

Quick Tip:


 You may use scissors to cut away entanglements of hair, or tweezers to unclog the notches inside bObi.




1. Press the latch on the side of the main brushes. Lift the locking bar up and remove the main brushes.



2. Use the cleaning tool to remove debris from the ends of the brush as well as the brush compartment.



3. Remove and clean the rubber brush ends. Make sure the metal cores remain in place before replacing the brush ends.



4. When done, starting with the rubber brush, replace the brushes and lower the locking bar until it clicks and locks into place.


Side Brush

To maximize bObi's efficiency, it is best to clean her side brush about once a week.

Parts You'll Need:



Philips Head
Screwdriver





Cleaning Tool

Cleaning bObi's Side Brush

Quick Tip:




You may use scissors to cut away entanglements of hair, or tweezers to unclog the notches inside bObi.



1. Remove the screw on the side brush using a Philips head screwdriver.

2. Clean the brush and the brush socket using bObi's cleaning tool.



3. When done, replace the side brush and screw.

Sensors




To maximize bObi's efficiency, it is best to clean her sensors about once a week. bObi's obstacle/wall sensors are located along her bumper; her edge sensors are located along the front of her underside.

Parts You'll Need:



Cloth
(not included)

Cleaning bObi's Sensors



1. Wipe the obstacle/wall and edge sensors with a soft cloth slightly dampened with cold water or alcohol.

Front Wheel



To maximize bObi's efficiency, it is best to clean her front wheel about once a week.

Parts You'll Need:




Flat Head
Screwdriver
(not included)

Cleaning bObi's Front Wheel



1. Pop the front wheel out of its socket using a flat head screwdriver.



2. Clean the wheel and the socket then replace the wheel and press until locked in place.

Parts and Accessories

bObi's additional features include a mop attachment, edge sensors, and a lithium-ion battery.

- 61 Mop
- 63 Edge Sensors
- 65 Battery




Mop

bObi's mop attachment allows her to mop as she vacuums and sweeps.


Quick Tip:

 Do not let bObi climb onto carpet or rugs when she is mopping. You may use bIOck to keep her away from carpet or rugs.




Installing bObi's Mop Attachment

1. Dampen bObi's mopping cloth with water or cleaning solution before placing it on the mop attachment.
2. Align the prongs of the mop attachment between bObi's wheels and press down, then lock in place.



Removing bObi's Mop Attachment

1. Grip the button on the back of the mop attachment and pull up to unlock, then lift until it's perpendicular to bObi, and pull up to detach.



Edge Sensors

If bObi repeatedly backs up or displays an error message (Er 01) while cleaning dark-colored carpet, then you'll need to deactivate the edge sensors. Make sure bObi's is turned ON before proceeding.


Parts You'll Need:



Blindfold Stickers

Quick Tip:


 When the edge sensors are deactivated, bObi is unable to detect stairs or sharp drops. You may use bOck to keep her away from these obstacles.



Deactivating bObi's Edge Sensors

Peel off the backs of each blindfold sticker and place one onto each of bObi's 4 edge sensors. Make sure each sensor is completely covered.

Remove the blindfold stickers, and wipe the sensor covers clean to reactivate bObi's edge sensors.



Battery

On her default Deep Clean mode, bObi's battery lasts about 45 – 90 minutes per charge. bObi's battery has a 2-year warranty. Replacement batteries can be purchased at www.bobsweep.com/shop.

Parts You'll Need:



Phillips Head
Screwdriver



Quick Tips:




To conserve bObi's battery, flip her power switch OFF and remove her from her charging station when she is not in use. bObi should not sit on her charging station for more than 5 days.




If you are not using bObi for an extended period of time, unplug her charging station, remove her battery, and store everything in a dry, room-temperature place away from direct sunlight.



1. Remove the 2 screws on the battery cover using a Phillips head screwdriver.



2. Disconnect the old battery by pulling the plug, not the wires. Plug in your new battery.



3. Slide the new battery into the compartment and replace the screws on the battery cover.

Troubleshooting

If bObi is having a problem with one of her parts, an error message will light up on her remote screen.

- 69 ER 01 : Edge Sensors
- 71 ER 02 : Brushes
- 73 ER 03 : Power System
- 75 ER 04 : Wheels
- 77 ER 05 : Dustbin

If the problems persist, please contact our helpful support team at support@bobsweep.com or 1-888-549-8847. Our business hours are Monday – Friday, 9 a.m. – 5 p.m. Pacific Time.




Edge Sensors: Er 01

Parts You'll Need:





Cloth
(not included)



What to do:

1. Wipe the edge sensors with a soft cloth slightly dampened with cold water or alcohol.
2. If problems persist, deactivate the edge sensors using bObi's blindfold stickers.



When the edge sensors are deactivated, bObi is unable to detect stairs or sharp drops. You may use bLOck* to keep her away from these obstacles.


* Available to purchase separately.

Brushes: Er 02


Parts You'll Need:



Compressed Air
(not included)




Cleaning Tool



What to do:

1. Remove and clean bObi's brushes and brush holders.
2. Clean the brush compartment from end to end using bObi's cleaning tool and compressed air.



bObi's main brush is not designed to clean shag carpet or rugs with long fibers. If you'd like bObi to clean shag carpet or long-fibered rugs, you may remove her main brush and allow her to vacuum without it.


Quick Tip:




You may use scissors to cut away entanglements of hair, or tweezers to unclog the notches inside bObi.

Power System: Er 03

Parts You'll Need:




Charging Adapter



Charging Station




Phillips Head Screwdriver



What to do:

1. Place bObi on her charging station and allow her to fully charge.
2. If bObi is unable to charge on her station, charge her directly by plugging the charging adapter into the inlet above her power switch.
3. If bObi still has trouble charging, try reconnecting the battery. Flip bObi's power switch OFF.



Wheels: Er 04


Parts You'll Need:



Cleaning Tool




Compressed Air
(not included)



What to do:

1. Use the cleaning tool to remove debris jamming bObi's wheels.
2. Remove the two screws around each wheel and use compressed air to remove debris inside the wheel compartments.



Dustbin: Er 05


Parts You'll Need:



Cleaning Tool




Compressed Air
(not included)



What to do:

1. Remove bObi's dustbin and empty it.
2. Gently wipe the two metal connectors on the bottom of the dustbin with a dry cloth. If the two metal connectors seem damaged, they may need to be replaced.
3. Lastly, clean the metal contact points inside bObi where the dustbin is inserted. If one or both of the contact points are stuck, use a screwdriver to gently pull them out.
4. Carefully reinstall the dustbin while bObi is in the upright position, so that the dustbin securely locks.



Home Checkup Test


If bObi is not performing as well as she should, you can diagnose the problem with a simple home checkup test.

81 Putting bObi in Checkup Mode

83 Home Checkup Test Steps




Putting bObi in Checkup Mode



1. Flip bObi's power switch OFF.
2. While holding down the OK button on bObi's remote, flip bObi's power switch ON, then simultaneously press WAFFLE and JUICE on bObi's cover.

 bObi will chirp 3 times to let you know she is now in checkup mode. You may release the OK button. Do not press any additional buttons on bObi or her remote.


When In Checkup Mode:



Current and scheduled times disappear from the remote's screen and new indicators appear as the test progresses: Numbers 1 to 7 display status of bObi's sensors.

The four-digit number in the center – Value Indicator – displays various measures of bObi's parts.

The Checkup Indicator displays the step of the test bObi is in – starting at 0000.




During the test, GO!, JUICE, and WAFFLE all remain lit on bObi's cover, and charging indicators cycle sequentially.

Quick Tip:

! Use the RIGHT button on bObi's remote to cycle through each step of the Checkup Test. Use the LEFT button to alternate between subsections of each step.

Step 1: 0000

Edge and Wheel Sensors



With bObi on the ground look at the remote's screen.

The 4 bars below numbers 1 to 4 should be underlined. Lift bObi about 6 inches (15 cm) off the ground and the lines below numbers 1 to 4 disappear, while numbers 5 and 6 are underlined.

Step 2: 0001

Firmware Version



Press LEFT on the remote. The Checkup Indicator changes to 0001.

The four-digit number in the center of the screen indicates bObi's firmware version.

Step 3: 0002

Battery




Press LEFT on the remote and Checkup Indicator changes to 0002.

The four-digit number in the center of the screen indicates the battery voltage in millivolts (mv).

A fully charged battery should have a voltage between 1200 and 1600 mv. If the number is below 1200, charge bObi overnight and repeat the test. If bObi is fully charged and the number is 0000 mv, flip bObi, open the battery compartment, and check the wiring connectivity.

Step 4: 0100

Wall Sensors



Press RIGHT on the remote and the Checkup Indicator changes to 0100.

Drag a thick, flat, and light-colored surface around bObi's bumper. Numbers 1 to 5 at the top of the remote will become underlined one at a time as you move your surface from the left side of bObi's bumper around to the right side.


The far right sensor is less sensitive than the others, so it may not respond the first few passes.

Quick Tip:

! bObi should not be tested while on the charging station.

Step 5: (0100 continued)

Touch Sensors



80 touch sensors surround bObi's bumper.


Press on any of the touch sensors on the left side of bObi's bumper, and number 6 at the top of the remote should be underlined.

Press on any of the touch sensors on the right side of the bumper, and number 7 at the top of the remote should be underlined; .

When you release the bumper, the lines should disappear.

Step 6: 0200

Battery Life, (and bLOck)



Press **RGHT** on the remote and the Checkup Indicator changes to 0200.


The four-digit number on the remote indicates the number of times bObi's battery has been used.

If you would like to test a bObi bLOck, unplug the charging station so its signal does not interfere with this test.

Place the bLOck with its front facing bObi. Turn on the bLOck. Number 5 at the top of the remote should be underlined. If 5 is not underlined, sync bObi and bLOck and repeat this step.

Step 7: 0300

Wheels, Brushes, and Vacuum



With an emptied dustbin attached to bObi, flip bObi over onto a flat surface to keep her from running away!


Press **RGHT** on the remote. The Checkup Indicator changes to 0300.

bObi's wheels and brushes should spin, and air should flow out of the dustbin.

Numbers 1 and 3 at the top of the remote should be underlined, indicating that the wheels' sensors are working.

Step 8: 0400

Charging Station



Plug the charging station.

Press **RGHT** on the remote. The Checkup Indicator changes to 0400.

Place bObi on her charging station with charging nodes touching.

The four-digit number on the remote displays a number ranging from 0020 to 0200 to confirm that bObi and her station are working well together.

If the number is between 0400 and 0800, let bObi charge overnight and repeat the test.

FAQs

Still have questions that we haven't answered? Contact our helpful support team at support@bobsweep.com or [1-888-549-8847](tel:1-888-549-8847). Our business hours are Monday – Friday, 9 a.m. – 5 p.m. Pacific Time.



My bObi won't turn on no matter what I do.

First, make sure bObi's power switch is turned ON. The power switch is located on bObi's side. If bObi's power switch is turned ON and she is not responding to her cover buttons, then her battery has likely drained too low for her to operate. Place bObi on her charging station and allow her to fully charge.

Why is bObi beeping?

bObi beeps periodically while in standby mode. You may mute her beeping by flipping her power switch OFF or by placing her on the charging station.

bObi also beeps when she encounters a problem and needs assistance. In addition to beeping, she will display an error message on her remote. Consult the Troubleshooting section of this manual for solutions.

How do I know that bObi is fully charged and ready to clean?

When bObi is charging, the center light on her cover flashes. When she is fully charged, the light remains still.

bObi just stopped cleaning and her screen turned off. What do I do next?

bObi may be in standby mode. If this is the case, pressing any button on her cover or FullCommand™ remote should wake her. If this does not work, her battery is likely completely drained. Place bObi on her charging station and allow her to fully charge.

How often should I empty the dustbin?

Depending on the size of the room and the amount of debris piled up, bObi may be able to perform up to 6 cleaning cycles before filling her dustbin. Simply remove the dustbin and check to see if emptying is necessary.

bObi is having trouble finding her charging station.

First, sync the charging station. Start by flipping bObi's power switch OFF. Then, press down the SYNC button on the back of the station using the syncing tool and flip bObi's power switch ON. bObi will chirp twice to confirm the sync was successful. If after syncing the station bObi is still having trouble finding it, relocate the station to a more easily accessible location with more space around it. Make sure the station is against a wall on a flat, level surface.

I am having problems removing bObi's brushes.

Open the brush compartment and gently wriggle them while pulling up. Do not force the brushes out, as this can damage them. You may use scissors to cut away entanglements of hair, or tweezers to unclog the notches inside bObi. It is best to clean bObi's brushes about once a week to prevent buildup.

How often should I clean bObi's brushes?

To maximize bObi's efficiency, it is best to clean her brushes about once a week. Remember to also clean the notches inside bObi that hold the brushes in place.

To watch bObi Pet's how-to videos visit www.bobsweep.com/bobi-classic-support or download the bObsweep App on your iOS or Android device.

What is bObi's runtime? How long should bObi's battery last?

The exact runtime depends on the age of the battery and the type of surface bObi is cleaning; the younger the battery and the smoother the cleaning surface, the longer the runtime. The normal runtime range for bObi is 45 – 75 minutes.

bObi's battery comes with a 2-year warranty and should last for several years. To conserve bObi's battery, do not leave her on her charging station for more than 5 days. If you are not using bObi regularly, remove her from her station and flip her power switch OFF.

What is the best way to clean bObi's wheels?

Use compressed air to clear the wheels of debris, or wipe the wheels as they spin during the checkup test. For a more thorough clean, you may remove the wheels completely. See bObi's wheel repair guide on www.bobsweep.com/bobi-classic-support for detailed instructions.

* Available to purchase separately.

bObi gets stuck under my furniture or travels over wires that tangle up her brush. How can I stop her from going into certain areas?

If bObi maneuvers under a piece of furniture and there is only one open entrance, he may need a few minutes to find her way out. If bObi does need help, she'll stop cleaning completely, beep, and display a trouble message.

If you would like bObi to avoid a certain area, such as an area with lots of wires, you may use bLOck* to create a digital barrier.

bObi is showing Er on her remote. How can I fix this?

bObi's error messages identify the specific parts on bObi that need help. Consult the Troubleshooting section of this manual for solutions.

Why does bObi start up when I did not tell him to clean?

bObi is either scheduled to clean or is on auto-resume mode.

First, make sure the current time and day is set correctly on bObi's FullCommand™ remote. Remember, bObi works on a 24-hour clock. If the current time and day is incorrect, then bObi's cleaning schedule will be out of sync.

Consult the Scheduling section of this manual for detailed instructions on how to reset bObi's cleaning schedule.

On auto-resume mode, bObi automatically begins cleaning after every recharge. When bObi is on auto-resume, she displays "FFGO" on her remote. To disable auto-resume, press the SCH TIME button on bObi's remote. Then press STOP. The remote will reset to the last time saved.

Press SCH TIME again to save your settings.

I think my bObi is broken. What do I do next?

Don't worry, a customer service agent will work with you personally to ensure you have a healthy, fully functional bObi. To connect with an agent, call [1-888-549-8847](tel:1-888-549-8847) or email support@bobsweep.com. Our hours are Monday – Friday, 9 a.m. – 5 p.m. PT.

End User Agreement



IMPORTANT - READ BEFORE USING. Do not use the robot (“Bobsweep”) accompanying this license agreement (“Agreement”) until you have carefully read and agreed to the following terms and conditions.

By using the Bobsweep, you agree to the terms of this End User License Agreement (“EULA”) and any amendment or addenda accompanying this Agreement. If you do not agree to the terms of this EULA, you may not use the Bobsweep. The Bobsweep contains an electronic and software interface that allows you to control or modify its behavior, and remotely monitor its sensors.

THIS IS A LEGAL AGREEMENT. BY ACCESSING AND USING THE PRODUCT AND PRODUCT SOFTWARE, YOU ARE ACCEPTING AND AGREEING TO THIS EULA ON BEHALF OF YOURSELF OR THE ENTITY YOU REPRESENT IN CONNECTION WITH THE ACCESS. YOU REPRESENT AND WARRANT THAT YOU HAVE THE RIGHT, AUTHORITY, AND CAPACITY TO ACCEPT AND AGREE TO THIS EULA ON BEHALF OF YOURSELF OR THE ENTITY YOU REPRESENT. YOU REPRESENT THAT YOU ARE OF SUFFICIENT LEGAL AGE IN YOUR JURISDICTION OR RESIDENCE TO USE OR ACCESS THE PRODUCT SOFTWARE AND TO ENTER INTO THIS EULA. IF YOU DO NOT AGREE WITH ANY OF THE PROVISIONS OF THESE TERMS, YOU SHOULD CEASE USING THE PRODUCT AND PRODUCT SOFTWARE.

Terms and Conditions

LICENSE: Subject to all of the terms of this Agreement, Bobsweep Inc. (“Bobsweep”) grants to you one (1) revocable, royalty-free, personal, non-exclusive, non-transferable, non-assignable, non-commercial intellectual property license to use the Bobsweep software contained on the Bobsweep (“Bobsweep Software”), including the protocol for communicating with the Bobsweep Software, and to use the Bobsweep.

NONCOMMERCIAL LICENSE: You may use the Bobsweep Software and the Bobsweep only for personal, non-commercial, educational, and research purposes. The Bobsweep Software and the Bobsweep may not be used for any other purpose, whether “for prot” or “not for prot.” Any work performed or produced using the Bobsweep, including any software that you create for your Bobsweep (“Your Software”), cannot be performed or produced for the benefit of other parties for a fee, compensation, or any other reimbursement or remuneration. A separate license is required for each additional use and/or individual user in all other cases. If you are an entity, Bobsweep grants you the right to designate one individual within your organization to have the sole right to use the Bobsweep Software and the Bobsweep in the manner provided above.

RESTRICTIONS: You agree not to: (i) use or copy the Bobsweep Software or the Bobsweep except as provided in this Agreement; (ii) rent or lease the Bobsweep Software or the Bobsweep to any third party; (iii) assign this Agreement or transfer the Bobsweep Software or the Bobsweep except as provided in this Agreement; (iv) modify, adapt, or translate the Bobsweep Software or the Bobsweep in whole or in part except as expressly provided in this Agreement; (v) reverse engineer, reverse compile, or disassemble the Bobsweep Software or the Bobsweep; or (vi) distribute, sublicense or transfer the source code form of Your Software and derivatives thereof to any third party except as provided in this Agreement.

YOUR SOFTWARE : Your Software is also subject to the following limitations: You (i) shall be solely responsible for any update or support obligation or other liability which may arise from your use or distribution, (ii) shall not make any statement that Your Software is “certified,” or that its performance is guaranteed, by Bobsweep, (iii) shall not use Bobsweep’s name or trademarks, (iv) shall prohibit disassembly and reverse engineering of the Bobsweep Software and the Bobsweep, (v) shall not publish reviews of Bobsweep products designated as beta without written permission from Bobsweep, and (vi) shall indemnify, hold harmless, and defend Bobsweep and its suppliers from and against any claims or lawsuits, including attorney’s fees, that arise or result from Your Software, including your use and your distribution.

TITLE: Title to the Bobsweep Software remains with Bobsweep or its suppliers. The Bobsweep Software is licensed, not sold. Except as expressly provided herein, Bobsweep does not grant any express or implied right to you under Bobsweep patents, copyrights, trademarks, or trade secret information. You will not remove any copyright or patent notice from the Bobsweep Software or the Bobsweep.

ONE-TIME TRANSFER: The initial user of the Bobsweep Software and the Bobsweep may make a one-time permanent transfer of this Agreement, the Bobsweep Software, and the Bobsweep to another end user, provided that the initial user retains no copies of the Bobsweep Software and the Bobsweep. This transfer must include the Bobsweep Software, the Bobsweep, and all of the materials accompanying the Bobsweep (including all component parts and printed materials, any upgrades, and this End User License Agreement document). The transfer may not be an indirect transfer, such as a consignment. Prior to the transfer, the end user receiving the Bobsweep Software and the Bobsweep must agree to all the terms of this Agreement.

NO WARRANTY AND LIMITED REPLACEMENT: EXCEPT AS STATED IN THE LIMITED WARRANTY TO THE ORIGINAL PURCHASER, THE BOBSWEEP SOFTWARE AND THE BOBSWEEP ARE PROVIDED “AS IS” WITH NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION, OR SAMPLE. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY BOBSWEEP OR ITS AGENTS SHALL CREATE A WARRANTY. If the Bobsweep Software or the Bobsweep is found to be defective in material or workmanship under normal use for a period of one (1) year from the date of receipt, Bobsweep’s entire liability and your exclusive remedy shall be the replacement of the Bobsweep Software or the Bobsweep. This offer is void if the defect results from accident, abuse, misapplication, or software that you developed for your Bobsweep. Any updates or supplements to the Bobsweep Software or the Bobsweep provided to you after the expiration of the one (1) year period are not covered by any warranty or condition, express, implied or statutory. **SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU. LIMITATION OF LIABILITY: THE ABOVE REPLACEMENT PROVISION IS THE ONLY WARRANTY OF ANY KIND. BOBSWEEP OFFERS NO OTHER WARRANTY EITHER EXPRESS OR IMPLIED INCLUDING THOSE OF MERCHANTABILITY, NON INFRINGEMENT OF THIRD- PARTY INTELLECTUAL PROPERTY OR FITNESS FOR A PARTICULAR PURPOSE. NEITHER BOBSWEEP NOR ITS SUPPLIERS SHALL BE LIABLE FOR ANY DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, VICARIOUS LIABILITY, CONSEQUENTIAL DAMAGES, INCIDENTAL DAMAGES, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR OTHER LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THE BOBSWEEP SOFTWARE, THE BOBSWEEP, OR SOFTWARE THAT YOU DEVELOPED FOR YOUR BOBSWEEP, EVEN IF BOBSWEEP HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME JURISDICTIONS PROHIBIT THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU UNAUTHORIZED USE: THE BOBSWEEP SOFTWARE AND THE BOBSWEEP ARE NOT DESIGNED, INTENDED, OR AUTHORIZED FOR USE IN ANY AERONAUTICAL, NUCLEAR, MEDICAL, LIFE SAVING OR LIFE SUSTAINING SYSTEMS, OR FOR ANY OTHER APPLICATION IN WHICH THE USE OF THE BOBSWEEP SOFTWARE OR THE BOBSWEEP COULD CREATE A SITUATION WHERE PERSONAL INJURY OR DEATH MAY OCCUR.** Should you use the Bobsweep Software or Bobsweep for any such unintended or unauthorized use, you shall indemnify and hold harmless Bobsweep and its officers, subsidiaries and affiliates against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of product liability, personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Bobsweep was negligent regarding the design or manufacture of the Bobsweep Software, the Bobsweep, or any part or portion thereof.

USER SUBMISSIONS: You agree that any material, information or other communication, including all data, images, sounds, text, and other things embodied therein, that you transmit or post to a Bobsweep website or provide to Bobsweep (“Communications”) will be considered non-confidential. Bobsweep will have no confidentiality obligations with respect to the Communications. You agree that Bobsweep and its designees will be free to copy, modify, create derivative works, publicly display, disclose, distribute, license and sublicense through multiple tiers of distribution and licensees, incorporate and otherwise use the Communications, including derivative works thereof, for any and all commercial or non-commercial purposes without the payment of any royalty to you, and that such license will survive the termination of this Agreement.

TERMINATION: This Agreement becomes effective on the date you accept this Agreement and will continue until terminated as provided for in this Agreement. You may terminate this Agreement voluntarily at any time. Bobsweep may terminate this Agreement at any time if you are in breach of any of its terms and conditions, and may refuse to license the Bobsweep Software or the Bobsweep to you after termination. Upon termination by either party, you will immediately return to Bobsweep or destroy the Bobsweep Software and the Bobsweep and all your copies thereof. Articles 5 and 7 through 17 of this Agreement shall survive such termination. **U.S. GOVERNMENT RESTRICTED RIGHTS:** The Bobsweep Software and the Bobsweep are provided with “RESTRICTED RIGHTS.” Use, duplication or disclosure by the Government is subject to restrictions set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor. Use of the Bobsweep Software or the Bobsweep by the Government constitutes acknowledgment of Bobsweep’s rights in them.

NO EXPORT: You may not export the Bobsweep Software or the Bobsweep in violation of applicable export laws.

INTERPRETATION PROVISION: The provisions of this Agreement are severable. If any provision of this Agreement is held to be unenforceable, such provision shall be reformed only to the extent necessary to make it enforceable. Any law or regulation which provides that the language of a contract shall be construed against the drafter shall not apply to this Agreement.

INTEGRATION: This Agreement represents the complete agreement concerning the subject matter hereof, and any and all understandings, conversations and communications, proposals, and counterproposals, oral and written (including any draft of this Agreement) are merged into and superseded by this Agreement and shall be of no force or effect, except as expressly provided herein. No such understandings, conversations, communications, proposals, counterproposals or drafts shall be referred to in any proceeding concerning this Agreement. Further, no understanding contained in this Agreement shall be modified, altered or amended, except by a writing signed by the party against whom enforcement is sought.

ARBITRATION: All disputes relating to this Agreement (excepting any dispute relating to intellectual property rights) shall be subject to final and binding arbitration, with the losing party paying all costs of arbitration. Any arbitration relating to this Agreement shall be held in California, under the auspices of an arbiter selected by Bobsweep. Any litigation relating to this Agreement shall be subject to exclusive venue and jurisdiction in the federal and state courts of California, with the losing party responsible for costs, including without limitation, court costs and reasonable attorneys fees and expenses.

APPLICABLE LAWS: Any claim arising under or relating to this Agreement shall be governed by the internal substantive laws of the Commonwealth of California, without regard to its principles of conflict of laws. The application of the United Nations Convention on Contracts for the International Sale of Goods is expressly excluded.